

MALE DISCONNECT INSTRUCTIONS




FIG. 1

- CAUTION:**
ALWAYS DISCONNECT POWER
BEFORE CONDUCTING MAINTENANCE
ON ANY ELECTRICAL PRODUCT
1. REMOVE NUT FROM NON-ELECTRICAL END CAP.
 2. REMOVE NON-ELECTRICAL END CAP
 3. SLIDE LAMP ASSEMBLY, WITH ELECTRICAL END CAP ATTACHED, OUT OF HOUSING TUBE.
 4. REMOVE ELECTRICAL END CAP
 5. SCREW MALE DISCONNECT INTO THREADED OPENING IN ELECTRICAL END CAP

NOTE: END CAP THREADS 1/2"-14 NPT
USE SILICONE OR APPROVED
SEALANT ON CONNECTOR THREADS
TO INSURE WET SEAL OF FIXTURE.

6. ATTACH DISCONNECT WIRES TO BALLAST SUPPLY WIRES (BLACK/BLACK-WHITE/WHITE-GREEN/GREEN) USING SPLICE CAPS SUPPLIED W/DISCONNECT.
7. FEED WIRES FROM DISCONNECT BACK INTO BALLAST ENCLOSURE.
8. REASSEMBLE FIXTURE IN REVERSE ORDER OF DISASSEMBLY INSTRUCTIONS. (1 THRU 4)




FIG. 2

LOCKWASHER & NUT

LINK

COLORLED CODED WIRES

MOUNTING BOLT

TO ASSEMBLE THE CHAIN MOUNTS:

1. SLIDE A LINK (WITH CHAIN) ON EACH MOUNTING BOLT.
2. INSTALL LOCKWASHERS & NUTS.

ALWAYS INSURE POWER SOURCE AND LABEL INFORMATION ARE THE SAME.

FIG. 3

