


FPF SERIES INSTRUCTIONS




WITH LAMP/BALLAST ASSEMBLY OUT,
RELAMP FIXTURE.
(SEE NAME PLATE FOR LAMP TYPE)

REASSEMBLE FIXTURE IN REVERSE
ORDER OF FIG. 1 INSTRUCTIONS.

NOTE: TUBE MUST SEAT IN
GROOVE ON END CAP.

FIG. 1

FIG. 2



ALWAYS INSURE POWER SOURCE AND
LABEL INFORMATION ARE THE SAME.

MAKE ELECTRICAL CONNECTION WITH
COLOR CODED WIRES.

TO CHANGE POWER CORD ASSEMBLY:

1. LOOSEN COMPRESSION CAP ON POWER CORD.
2. SLIDE COMPRESSION BUSHING AWAY FROM FIXTURE.
3. UNSCREW CONNECTOR BODY FROM END CAP.
4. PULL WIRE ASSEMBLY OUT OF FIXTURE (THREE WIRES
WITH SPLICE CAPS WILL PULL THROUGH END OF FIXTURE).
5. CONNECT NEW POWER CORD TO THREE WIRES FROM FIXTURE
(BLACK TO LINE/WHITE TO COMMON/GREEN TO GROUND).
6. PUSH WIRES BACK INTO HOUSING AND TIGHTEN NEW
CORD/CONNECTOR IN END CAP.

NOTE: END CAP THREADS 1/2"-14 NPT
USE SILICONE OR APPROVED
SEALANT ON CONNECTOR THREADS
TO INSURE WET SEAL OF FIXTURE.