


FPF SERIES INSTRUCTIONS



1. REMOVE NUT FROM NON-ELECTRICAL END CAP. (SEE ILLUSTRATION)
2. REMOVE NON-ELECTRICAL END CAP
3. SLIDE LAMP/BALLAST ASSEMBLY, WITH ELECTRICAL END CAP ATTACHED, OUT OF HOUSING TUBE. (SLIDE FROM ELECTRICAL END)

FIG. 1

WITH LAMP/BALLAST ASSEMBLY OUT,
RELAMP FIXTURE.

(SEE NAME PLATE FOR LAMP TYPE)

REASSEMBLE FIXTURE IN REVERSE
ORDER OF FIG. 1 INSTRUCTIONS.

NOTE: TUBE MUST SEAT IN
GROOVE ON END CAP.




FIG. 2

TO ASSEMBLE THE CHAIN MOUNTS:

1. SLIDE A LINK (WITH CHAIN) ON EACH MOUNTING BOLT.
2. INSTALL LOCKWASHERS & NUTS.

ALWAYS INSURE POWER SOURCE AND
LABEL INFORMATION ARE THE SAME

MAKE ELECTRICAL CONNECTION WITH
COLOR CODED WIRES.

TO CHANGE POWER CORD ASSEMBLY:

1. LOOSEN COMPRESSION CAP ON POWER CORD.
2. SLIDE COMPRESSION BUSHING AWAY FROM FIXTURE.
3. UNSCREW CONNECTOR BODY FROM END CAP.
4. PULL WIRE ASSEMBLY OUT OF FIXTURE (THREE WIRES WITH SPLICE CAPS WILL PULL THROUGH END OF FIXTURE).
5. CONNECT NEW POWER CORD TO THREE WIRES FROM FIXTURE (BLACK TO LINE/WHITE TO COMMON/GREEN TO GROUND).
6. PUSH WIRES BACK INTO HOUSING AND TIGHTEN NEW CORD/CONNECTOR IN END CAP.

NOTE: END CAP THREADS 1/2"-14 NPT
USE SILICONE OR APPROVED
SEALANT ON CONNECTOR THREADS
TO INSURE WET SEAL OF FIXTURE.




FIG. 3